

Cooling Elements

Application

At high measuring-point temperatures a capillary tube should be used. Then the pressure gauge remains at ambient temperature and temperature-related errors are avoided.

In cases in which the installation of a capillary tube is not possible due to technical reasons, we offer cooling elements for various temperature ranges. Please ensure that at the maximal temperatures indicated in the following table, convection at the cooling element is not hindered.

Cooling Element

Dimensions	Material	T max. [°C]	Ordering Code Ident. number
	Stainless steel	150	0400 N 05012.0002
	1.4435	200	0401 D 12361.0003
	1.4435	300	0402 D 12361.0002